



Zirconium Tungstate

INTRODUCTION

Zirconium Tungstate is a complex oxide that exhibits the unusual property of contracting, rather than expanding, as its temperature rises from near absolute zero to its decomposition-temperature near 1050°K (780°C). Throughout this range, Zirconium Tungstate has cubic symmetry, so that its thermal expansion is the same in any direction. Near 428°K (155°C), Zirconium Tungstate undergoes a second-order phase transformation to a disordered phase of higher symmetry, called β -Zirconium Tungstate to distinguish it from the α -phase, the form stable below 428°K. When exposed to pressure at room temperature, α -Zirconium Tungstate converts to a denser polymorph, called the γ -phase. This phase persists at atmospheric pressure, but reverts to the α -form when heated.

TYPICAL COMPOSITION

Table 1. Typical Chemistry (On as received basis ppm except where noted. Nominal Purity 99.5 (Zr+Hf))		
Element		Analysis
Al	Aluminum	<200
Fe	Iron	<200
Hf	Hafnium	<100
Si	Silicon	<400
Ti	Titanium	<100

FORMULA

ZrW_2O_8 .

DESCRIPTION

A fine white to light green powder.

PARTICLE SIZE

The typical median is 16 microns.

BULK DENSITY

Approximately 5072-5355 kg/m³

PACKAGING

Double plastic bags inside metal drums or polyethylene containers Polyethylene jars inside metal drums or polyethylene containers.

HANDLING

Data are typical and should not be construed as maximum or minimum values for specification or for final design. Data on any particular piece of material may vary from those herein. U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com



Technical Data Sheet

Zirconium tungstate is inert. Avoid personal contact and dust generating conditions. Store in a dry location away from combustibles. See MSDS for further information.

PHYSICAL PROPERTIES

Table 1. α -Zirconium Tungstate			
Appearance	White powder		
Formula	ZrW_2O_8		
Formula mass	586.91 g		
Crystal symmetry	Cubic		
Formula units per cell	4		
*Powder diffraction-pattern, 293K, three strongest peaks	h k l	d,nm	I/I max
	210	0.40957	100
	211	0.37388	78
	321	0.24476	34
Cell parameter	0.915993(5)nm, 293°K		
a-1 Transition temperature, 0.1 MPa	428°K		
Space group	P2, 3, 0°K<T≤428°K		
Density	5072 kg.m ⁻³ , 293°K		
Bulk modulus	69.4 GPa, 300°K		
Coefficient of thermal expansion	See Figure 1		
Average value	$-8.8 \times 10^{-6} K^{-1}$, 0°K<T<400°K		
Dielectric constant	See Figures 2, 4		
Loss tangent	See Figures 3, 4		
Conductivity, electrical	See Figure 5		
Refractive index, natural light	1.669±.002		
Solubility in water	<0.1 mg.l ⁻¹ , 293°K		
Reaction with boiling (0.1 MPa) 2N aqueous hydrochloric acid	None		
Reaction with boiling (0.1 MPa) 2N aqueous sodium hydroxide	Decomposes		
Decomposition temperature in air (0.1 MPa)	1050°K		
*The complete listing of powder diffraction-pattern peaks will be sent on request.			

Table 2. β -Zirconium Tungstate			
Appearance	White powder		
Crystal symmetry	Cubic		
Formula units per cell	4		
*Powder diffraction-pattern, 509°K, three strongest peaks	h k l	d,nm	I/I max
	210	0.4055	100
	211	0.3730	65
	321	0.2442	50
Cell parameter	0.91371(5) nm, 483°K		



Technical Data Sheet

α-β Transition temperature	428°K	
Space group	Pa 3	
Density	5110 kg.m ⁻³ , 483°K	
Coefficient of thermal expansion	See Figure 1	
Average value	-4.9 x 10 ⁻⁶ K ⁻¹ , 430°K<T<950°K	
Dielectric constant	See Figures 2, 4	
Loss tangent	See Figures 3, 4	
Conductivity, electrical	See Figure 5	

Table 3. γ-Zirconium Tungstate			
Transition pressure	210 MPa, 293°K		
Volume-change at transition	5.77 x 10 ⁻³ liter per gram formula-mass		
Crystal symmetry	Orthorhombic		
Formula units per cell	12		
*Powder diffraction pattern, 293°K, three strongest peaks	h k l	d,nm	I/I max
	160	0.40355	100
	201	0.40424	93
	231	0.36883	75
Cell parameters, 0.1 MPa	a: 0.9069 nm		
	b: 2.7020 nm		
	c: 0.8912 nm, 293°K		
Density, 0.1 MPa	5355 kg.m ⁻³ , 293°K		
Bulk modulus, 0.1 MPa	68.0 GPa, 300°K		
Temperature of reversion to cubic form	393°K		
Coefficient of thermal expansion, 0.1 MPa	a: -1.88 x 10 ⁻⁶ K ⁻¹ , 293°K		
	b: -0.68 x 10 ⁻⁶ K ⁻¹ , 293°K		
	c: -0.92 x 10 ⁻⁶ K ⁻¹ , 293°K		

Figure 1. Thermal Expansion of Zirconium Tungstate




Figure 2. Frequency dependence of dielectric constant of zirconium tungstate at four temperatures




Figure 3. Frequency dependence of dielectric loss-tangent of zirconium tungstate at four temperatures




Figure 4. Temperature dependence of dielectric constant and loss-tangent of zirconium tungstate measured at 1kHz




Figure 5. Temperature dependence of electrical conductivity of zirconium tungstate, deduced from impedance spectroscopy measurements.




Table 4. Diffraction Pattern of α -ZrW₂O₈

h	k	l	d-value, nm	Relative intensity
1	1	1	0.52875	14
2	0	0	0.45791	9
2	1	0	0.40957	100
2	1	1	0.37388	78
2	2	0	0.32379	17
2	2	1	0.30527	9
3	1	0	0.28961	17
3	1	1	0.27613	28
3	2	0	0.25400	18
3	2	1	0.24476	34
4	0	0	0.22896	3
4	0	1	0.22212	7
3	2	2	0.22212	4
3	3	1	0.21010	5
4	2	0	0.20478	5
4	2	1	0.19985	17
3	3	2	0.19525	3
4	2	2	0.18694	17



Technical Data Sheet

4	3	0	0.18316	7
5	1	0	0.17961	5
4	3	1	0.17961	11
5	1	1	0.17625	15
3	3	3	0.17625	9
5	2	0	0.17006	10
4	3	2	0.17006	7
5	1	2	0.16721	2
5	2	1	0.16721	3
4	4	0	0.16190	11
5	2	2	0.15942	1
4	4	1	0.15942	4
5	3	0	0.15706	7
5	3	1	0.15480	1
4	4	2	0.15264	2
6	1	0	0.15056	1
5	3	2	0.14857	6
6	1	1	0.14857	5
5	2	3	0.14857	5
6	2	1	0.14303	7

Table 5. Diffraction Pattern of -y-ZrW₂O₈

h	k	l	d-value	Relative intensity
0	2	0	1.35187	1
0	1	1	0.84709	17
1	2	0	0.75316	1
0	4	0	0.67593	7
1	3	0	0.63928	2
1	0	1	0.63596	4
0	3	1	0.63398	11
1	1	1	0.61906	3
1	2	1	0.57546	6
1	4	0	0.54197	1
0	4	1	0.53873	2
1	3	1	0.51962	9
1	4	1	0.46318	4
0	5	1	0.46241	5
2	0	0	0.45347	6



Technical Data Sheet

0	6	0	0.45062	18
2	1	0	0.44723	1
0	0	2	0.44600	11
2	2	0	0.42993	1
0	2	2	0.42355	1
1	5	1	0.41196	3
2	0	1	0.40424	93
1	6	0	0.40355	100
0	6	1	0.40221	3
1	0	2	0.40023	2
2	1	1	0.39979	5
0	3	2	0.39973	60
1	1	2	0.39591	3
1	2	2	0.38376	2
2	4	0	0.37658	1
2	3	1	0.36883	75
1	6	1	0.36768	51
1	3	2	0.36578	53
1	7	0	0.35536	3
0	7	1	0.35444	3
2	5	0	0.34747	6
2	4	1	0.34693	1
1	4	2	0.34438	1

Table 6. Diffraction Pattern of γ -ZrW₂O₈

h	k	l	d-value	Relative intensity
0	5	2	0.34407	5
0	8	0	0.33797	2
1	7	1	0.33013	6
2	5	1	0.32377	1
1	5	2	0.32170	6
2	6	0	0.31964	6
2	0	2	0.31798	10
0	6	2	0.31699	9
1	8	0	0.31669	1
0	8	1	0.31604	4
2	1	2	0.31580	23
2	2	2	0.30953	5
2	3	2	0.29986	24

Data are typical and should not be construed as maximum or minimum values for specification or for final design. Data on any particular piece of material may vary from those herein. U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Allegheny Technologies Incorporated
1000 Six PPG Place
Pittsburgh, PA 15222-5479 U.S.A.
www.ATImetals.com



Technical Data Sheet

1	6	2	0.29924	3
1	8	1	0.29844	1
0	1	3	0.29555	8
2	7	0	0.29404	4
0	7	2	0.29198	1
0	2	3	0.29039	8
3	0	1	0.28632	1
1	9	0	0.28518	1
0	9	1	0.28470	1
1	0	3	0.28254	4
0	3	3	0.28236	9
1	1	3	0.28101	4
3	2	1	0.28011	2
2	7	1	0.27926	2
1	7	2	0.27793	9
1	2	3	0.27656	1
3	4	0	0.27597	1
2	5	2	0.27410	2
3	3	1	0.27288	34
0	4	3	0.27217	2
1	9	1	0.27163	26
0	10	0	0.27037	1
1	3	3	0.26960	12
3	4	1	0.26364	2
1	4	3	0.26068	3
0	5	3	0.26054	6
2	6	2	0.25981	3
2	8	1	0.25928	3
1	10	0	0.25910	4

Table 7. Diffraction Pattern of γ -ZrW₂O₈

h	k	l	d-value	Relative intensity
0	10	2	0.25875	4
1	8	2	0.25822	2
3	6	0	0.25105	13
1	5	3	0.25042	1
3	1	2	0.24918	2
0	9	2	0.24916	10



Technical Data Sheet

1	10	1	0.24882	1
2	0	3	0.24865	8
0	6	3	0.24818	5
2	2	3	0.24455	2
3	6	1	0.24166	15
3	3	2	0.24112	8
2	9	1	0.24112	13
1	9	2	0.24026	9
2	3	3	0.23969	7
1	6	3	0.23938	4
1	11	0	0.23724	3
2	4	3	0.23336	1
2	8	2	0.23159	3
3	7	1	0.23001	1
1	11	1	0.22927	2
1	7	3	0.22804	5
3	5	2	0.22710	2
4	0	0	0.22674	8
4	1	0	0.22594	3
2	5	3	0.22591	2
0	12	0	0.22531	4
0	2	4	0.22003	2
4	3	0	0.21989	3
1	12	0	0.21866	2
2	9	2	0.21837	1
2	6	3	0.21771	1
4	2	1	0.21690	1
1	8	3	0.21677	5
4	4	0	0.21497	1
1	2	4	0.21382	4
4	3	1	0.21349	1
3	9	0	0.21309	1
1	12	1	0.21238	1
3	0	3	0.21199	1
1	3	4	0.21056	1
3	7	2	0.21002	4
4	5	0	0.20910	8



Technical Data Sheet

Table 8. Diffraction Pattern of γ -ZrW₂O₈

h	k	l	d-value	Relative intensity
4	4	1	0.20898	1
3	9	1	0.20726	1
3	3	3	0.20635	1
1	4	4	0.20623	3
2	10	2	0.20598	6
1	9	3	0.20581	2
4	5	1	0.20358	2
1	13	0	0.20272	2
4	6	0	0.20254	2
3	4	3	0.20227	1
4	0	2	0.20212	1
2	12	0	0.20178	3
3	10	0	0.20153	1
3	8	2	0.20111	3
0	12	2	0.20111	2
2	8	3	0.20028	1
2	0	4	0.20011	1
0	6	4	0.19987	3
2	1	4	0.19957	1
2	2	4	0.19796	2
1	13	1	0.19768	1
4	6	1	0.19752	2
3	5	3	0.19736	2
4	3	2	0.19722	15
2	12	1	0.19680	9
3	10	1	0.19658	3
1	12	2	0.19634	1
2	3	4	0.19535	1
1	10	3	0.19534	1
1	6	4	0.19518	1
2	11	2	0.19447	1
4	4	2	0.19365	2
3	9	2	0.19227	10
2	4	4	0.19188	10
3	6	3	0.19182	2
2	9	3	0.19155	1
4	7	1	0.19100	1

Data are typical and should not be construed as maximum or minimum values for specification or for final design.
Data on any particular piece of material may vary from those herein.
U.S. and foreign patents; other patents pending. © 2011 ATI. All rights reserved.

Technical Data Sheet

3	11	0	0.19071	1
4	5	2	0.18933	1
2	13	0	0.18905	1
0	13	2	0.18849	1
4	8	0	0.18829	1

Table 9. Diffraction Pattern of γ -ZrW₂O₈

h	k	l	d-value	Relative intensity
2	5	4	0.18767	6
3	11	1	0.18650	2
0	8	4	0.18613	1
3	7	3	0.18584	3
1	11	3	0.18544	4
2	13	1	0.18494	3
1	14	1	0.18479	3
1	13	2	0.18455	3
4	6	2	0.18442	2
4	8	1	0.18423	2
2	12	2	0.18384	2
2	10	3	0.18302	1
2	6	4	0.18289	9
1	8	4	0.18233	2
3	12	0	0.18066	1
4	0	3	0.18030	2
4	1	3	0.17990	2
3	8	3	0.17958	3
0	12	3	0.17958	2
3	0	4	0.17946	6
3	1	4	0.17907	3
0	9	4	0.17906	1
4	2	3	0.17871	3
0	1	5	0.17801	3
3	2	4	0.17790	5
5	0	1	0.17775	1
0	2	5	0.17687	1
4	3	3	0.17679	2
0	15	1	0.17668	3
5	2	1	0.17624	1



Technical Data Sheet

1	12	3	0.17616	6
1	9	4	0.17567	2
1	0	5	0.17505	1
0	3	5	0.17500	3
2	11	3	0.17480	1
1	1	5	0.17468	3
5	3	1	0.17439	9
4	4	3	0.17421	3
2	13	2	0.17405	5
1	14	2	0.17393	3
1	2	5	0.17360	3
3	4	4	0.17345	3

Table 10. Diffraction Pattern of γ -ZrW₂O₈

h	k	l	d-value	Relative intensity
1	15	1	0.17342	10
3	9	3	0.17321	5
0	4	5	0.17249	4
2	8	4	0.17219	2
0	10	4	0.17203	1
5	4	1	0.17191	1
1	3	5	0.17183	1
4	5	3	0.17104	3
4	10	1	0.17053	5
0	13	3	0.17042	5
3	5	4	0.17032	1
1	4	5	0.16946	1
1	10	4	0.16902	2
0	16	0	0.16898	3
5	5	1	0.16886	1
3	13	1	0.16827	3
5	6	0	0.16827	7
5	0	2	0.16803	1
4	9	2	0.16770	6
2	15	0	0.16750	2
1	13	3	0.16749	1
3	12	2	0.16744	3
4	6	3	0.16739	4



Technical Data Sheet

2	12	3	0.16696	1
3	10	3	0.16682	1
5	2	2	0.16674	1
3	6	4	0.16672	3
1	5	5	0.16654	2
1	16	0	0.16612	1

REFERENCES

For an interpretation of the negative normal expansion of zirconium tungstate in light of its crystal structure, see TA. Mary, J.S .O. Evans, T. Vogt, A. W Sleight, "Negative Thermal Expansion From 0.3K to 1050 Kelvin in ZrW_2O_8 ," Science, Vol. 272, 5 April 1996, pp. 90–92.

For a more detailed structure-based interpretation of zirconium tungstate's negative expansion, for structural data on the β -phase and for data on electrical properties, see "Negative Thermal Expansion in ZrW_2O_8 , and HfW_2O_8 ", J.S.O. Evans, T.A. Mary, T Vogt, M.A. Subramaniam and A.W Sleight, Chemistry of Materials Vol. 8, No. 12, pp. 2809–2823.

For a description and interpretation of the structure of the zirconium tungstate polymorph formed at high pressure see "Compressibility, phase transitions, and oxygen immigration in Zirconium Tungstate, ZrW_2O_8 ," J.S.O. Evans, Z. Hu, J.D. Jorgensen, D.N Argyriou, S. Short, A. W. Sleight, Science, Vol. 275, 3 January 1997, pp. 61–65.

For information on the thermal stability of zirconium tungstate, see "Condensed Phase Relations in the Systems ZrO_2 - WO_2 - WO_3 and HfO_2 - WO_2 - WO_3 ", L. L. Y. Chang, M.G. Scroger, and B. Philips, J. Am. Cer. Soc., Vol. 50, No.4, 1967, pp. 211-215, quoted in Phase Diagrams for Ceramists 1975 Supplement, Ernest M. Levin and Howard F. McMurdie, Ed.s, The American Ceramic Society, Columbus, Ohio, p. 173, Fig. 4459.